


# BA72/73 Touch Identification (Type Label Coding)

Example of Type label with Touch Screen Code (see arrow):



Explanation of Touch Screen Code:

X.0	No Touch
X.1	<b>3M</b> Touch (Resistive or Capacative Touch)
X.1-1	
X.1-2	
X.CT1	
X.4	
X.2	<b>ELO</b> Resistive Touch
X.3	<b>ELO</b> InfraRed Touch

**i** The variable X is not relevant for the identification.

Download **either** the ELO Touch driver **or** the 3M Touch driver from the Internet:

[http://www.wincor-nixdorf.com/internet/site\\_EN/EN/Support/Downloads/POSLotterySystems/Driver/Display/Display\\_node.html](http://www.wincor-nixdorf.com/internet/site_EN/EN/Support/Downloads/POSLotterySystems/Driver/Display/Display_node.html)

Install the **ELO** Touch driver for BA72/73 Touch screens labeled X.2 or X.3.  
Install the **3M** (Micro Touch) driver for all other BA72/73 Touch screens.

**i** Please mind that ELO and 3M drivers can not be operated in parallel.